

## Frozen Drink Machine Instructions

### MIXING STEPS FOR SUPERB FROZEN DRINKS!

#### Margaritas / Strawberry Margaritas

1. Use our 5-gallon bucket provided for mixing. (Bucket is property of Petrosh's Big Top.)
2. Empty contents of  $\frac{1}{2}$  gal. Petrosh mix into bucket. Add cold water to the water-line.
3. Add 3-liters of Tequila. If using 1.75-liter bottles, use one and one-half bottles.
4. Stir well. Slowly fill machine reservoir. Switch the machine to the "On" position at least one hour before the party.

#### Strawberry Daiquiri's

1. Use our 5-gallon bucket provided for mixing. (Bucket is property of Petrosh's Big Top.)
2. Empty contents of  $\frac{1}{2}$  gal. Petrosh mix into bucket. Add cold water to the water-line.
3. Add 2-liters of Rum. If using 1.75-liter bottles, use one and one-half bottles.
4. Stir well. Slowly fill machine reservoir. Switch the machine to the "On" position at least one hour before the party.

#### Pina Colada's

5. Use our 5-gallon bucket provided for mixing. (Bucket is property of Petrosh's Big Top.)
6. Empty contents of  $\frac{1}{2}$  gal. Petrosh mix into bucket. Add cold water to the water-line.
7. Add 2-liters of Rum. If using 1.75-liter bottles, use one and one-half bottles.
8. Stir well. Slowly fill machine reservoir. Switch the machine to the "On" position at least one hour before the party.

Stir well.

Slowly fill machine reservoir. Switch the machine to the "On" position at least one hour before the party.

**If machine keeps shutting off:**

1. Make sure nothing else is plugged into that same outlet. Try switching plug from top to bottom or vice versa.
2. Unplug/turn off any items that do not need to be on.
3. If #1 or #2 do not work, make sure that there is nothing else on the same circuit as the machine.

**If the machine is not freezing your drinks:**

1. Make sure the switch is to the left, the "On" position, not to the right, the "Clean" position.
2. If there are too many people per machine, it will not keep up. (100 people per machine) Use 10ounce cups or smaller.

**EACH DRINK MIX MAKES APPROXIMATELY 60-70  
6OZ DRINKS**

When making the second batch of drinks you can add some ice into the mixing bucket in place of water. \*\*\*Make sure the ice melts in the bucket before pouring the mix into the machine reservoir! This will bring the temperature of the water down and freeze the mixture more quickly.

**TIPS FOR TROUBLE-FREE OPERATIONS OF THE FROZEN DRINK  
MACHINE**

\*Make Sure You Have The Switch Pushed To The Left, The "On" Position!

- When the red "MIX LOW" light comes on, fill the reservoir. We recommend you add more mix before the "mix low" light comes on. DO NOT ALLOW MACHINE TO RUN IN ITS FREEZING MODE WHEN RESERVOIR BECOMES EMPTY.
- Use ONLY heavy duty 12 gauge wire extension cord provided. Damage will occur to machines if smaller than 12 gauge wire extension cord is used. YOU ARE RESPONSIBLE FOR ANY DAMAGE.
- Drawing too many drinks too fast causes them to become soupy. Wait 5 to 10 minutes for machine to recover.

- When party is almost over, you may allow reservoir to become empty by pushing the switch to the right, the "Clean" cycle. The freezing action is now off but still allows you to pour drinks. If freezing action were left on, the final drinks may freeze up and refuse to flow. It will also damage the machine.
- When the party is over, empty out any remaining mix. Switch to the 'CLEAN' position, pour a bucket of cold water through the machine. Empty and unplug the machine. Leave the cord, bucket and any unopened mix on the cart. We will return to pick up these items! Thank You!